



NOTES:

1. * Omit when using single phase supply
2. *₂ For Single Phase connections will be terminated to the live wire (Br)
3. To be read in conjunction with Drg No.s HST/1400/021 and HST/1400/023

Socket only required if specified / agreed by the Overseeing Organisation.

Notes				
IWP No.				
Drg. No. HST-1400-022				
Rev.				
Project Title				
HCC STANDARD DETAIL DRAWINGS				
Drawing Title				
THREE PHASE / 23 WAY GROUP SWITCHING PANEL WIRING DIAGRAM				
Sht No. 1 OF 1				
Scales NTS				

COUNTY HALL
 Pegs Lane
 Hertford, Herts
 SG13 8DN
 Phone: 01992 555555